



ALTRONIC RESEARCH, INC.

P.O. BOX 249, YELLVILLE, ARKANSAS, U.S.A. 72687-249

PHONE 870-449-4093 FAX 870-449-6000

1-800-482-LOAD (5623) in US

altronic.com

MODEL 1100 SERIES OIL COOLED RF COAXIAL LOAD Digital UHF, Max Stable Semiconductor



LIMITED WARRANTY

We take pride in manufacturing products of the highest quality, and we warrant them to the original purchaser to be free from defects in material and workmanship for the period of one year from date of invoice. Additionally, products of our manufacture repaired by us are warranted against defects in material and workmanship for a period of 90 days from date of invoice, with the provisions described herein.

Should a product or a portion of a product of our manufacture prove faulty, in material or workmanship, during the life of this warranty, we hereby obligate ourselves, at our own discretion, to repair or replace such portions of the product as required to remedy such defects. If, in our judgment, such repair or replacement fails to be a satisfactory solution, our limit of obligation shall be no more than full refund of the purchase price.

This warranty is limited to products of our own manufacture. Equipment and components originating from other manufacturers are warranted only to the limits of that manufacturer's warranty to us. Furthermore, we shall not be liable for any injury, loss or damage, direct or consequential, arising out of the use, or misuse (by operation above rated capacities, repairs not made by us, or any misapplication) of the equipment. Before using it, the user shall determine the suitability of the product for the intended use; and the user assumes all risks and liability whatsoever in connection therewith.

The foregoing is the only warranty for Altronic Research Incorporated and is in lieu of all other warranties expressed or implied.

Warranty returns shall first be authorized by the Customer Service Department and shall be shipped prepaid. **Warranty does not cover freight charges.**

TABLE OF CONTENTS

MODEL 1100 SERIES

<u>SECTION</u>	<u>PAGE</u>
Warranty	2
Warnings and Precautions.....	4
Introduction.....	5
I. Description and Leading Particulars	
1-1 Purpose and Application of Equipment.....	5
1-2 Equipment Supplied	5
1-3 Equipment Required But Not Supplied.....	5
1-4 General Description.....	5
1-5 Mechanical Description.....	5
1-6 General Principle of Operation.....	5
1-7 Operating and Adjustment Controls.....	5
1-8 Operator Training	6
II. Preparation for Use and Reshipment	
2-1 Unpacking Equipment	7
2-2 Pre-Installation Inspection.....	7
2-3 Pre-installation Test.....	7
2-4 Installation	7
2-5 Location	7
2-6 Mounting	7
2-7 Connections	8
2-8 Preparation for Reshipment.....	8
III. Operating Instructions	
3-1 Normal Operation.....	8
3-2 Shutdown.....	8
IV. Maintenance	
4-1 Cleaning.....	9
4-2 DC Resistance.....	9
4-3 Coolant.....	9
4-4 RF Circuit	10
4-5 Resistor Replacement	10
V. Drawings	
Outline Drawings.....	11
Wiring Schematic (Model 1110)	13
VI. Specifications.....	14

PRECAUTIONS

⚡DANGER⚡

Do not attempt any service or parts replacement without first disconnecting all RF power. Failure to do so may result in serious or *fatal electrical shock*.

WARNING

The thermal interlock switch indicates an overtemperature condition of the load and is not to be used for VSWR fault or transmitter protection.

WARNING

The vent plug must be used at all times when operating the unit or when the unit is cooling. Failure to do so could result in an explosion causing severe burns.

WARNING

OPERATING TEMPERATURE

Care should be taken to operate unit below stated maximum operating temperature. OPERATION ABOVE RATED TEMPERATURE MAY CAUSE DAMAGE TO UNIT AND OTHER EQUIPMENT AND PERSONNEL

CAUTION

DO NOT APPLY MORE THAN RATED POWER TO UNIT.
DAMAGE CAN OCCUR IF LARGE OVERLOADS, TEMPORARILY OR PERMANENTLY, ARE APPLIED.

INTRODUCTION

This handbook was prepared for skilled personnel as an aid in understanding and performing installation, service and maintenance procedures for the Model 1100 Series RF Coaxial Load. Personnel are considered to be skilled if they have the necessary knowledge and practical experience of electrical and radio engineering to appreciate the various hazards that can arise from working on radio transmitters, and to take appropriate precautions to ensure the safety of personnel.

SECTION I

DESCRIPTION AND LEADING PARTICULARS

- 1-1. Purpose and Application of Equipment.** The Model 1100 Series RF Coaxial Loads are designed to safely dissipate their specified rated maximum of electrical energy within a frequency range of DC to 1 GHz in the regular series, and 470-890 MHz in the digital series. DC to 60 MHz for MS series.
- 1-2. Equipment Supplied.** The Model 1100 Series Loads are supplied with standard RF connectors as shown below.

<u>MODEL 1101</u> QC, Stub	<u>MODEL 11015</u> QC, Stub	<u>MODEL 11025</u> QC, Stub	<u>MODEL 1105</u> QC, 1-5/8"EIA, 3-1/8"EIA	<u>MODEL 1110</u> QC, 1-5/8"EIA, 3-1/8"EIA	<u>MODEL 1120</u> 3-1/8"EIA
<u>MODEL 1101D</u> QC, Stub	<u>MODEL 11015D</u> QC, Stub	<u>MODEL 11025D</u> QC, Stub	<u>MODEL 1105D</u> QC, 1-5/8"EIA, 3-1/8"EIA	<u>MODEL 1110D</u> QC, 1-5/8"EIA, 3-1/8"EIA	<u>MODEL 1120</u> 3-1/8"EIA

- 1-3. Equipment Required But Not Supplied.** The Model 1100 Series Loads are complete as supplied, but the user must furnish RF input, and alarm indicator cable.
- 1-4. General Description.** The Model 1100 Series Loads are enclosed in a single aluminum powder coated case. The RF connector is located on the front panel of the load.
- 1-5. Mechanical Description.** The Model 1100 Series Loads consist of a 50 ohm non-reactive resistor assembly which is cooled by biodegradable dielectric oil and ambient air. The vent plug located on top of the unit relieves internal pressure created from coolant expansion.
- 1-6. General Principle of Operation.** After ascertaining that the Model 1100 Series Load is correctly connected to the RF source and the transmitter alarm, operate transmitter as desired.

1-7. Operating and Adjustment Controls. The Model 1100 Series Loads have no indicators or operating controls, nor are field adjustments necessary or possible.

1-8. Operator Training. The operator of this equipment must have the following skills/knowledge:

- An understanding of the purpose of the equipment.
- An understanding of the principles of operation of the equipment.
- An understanding of the normal operating procedures for the equipment.
- An understanding of the normal and abnormal indications which may be presented at the control point.
- The proper procedures for starting, using and stopping the equipment under normal conditions.
- The proper procedure for stopping the equipment under abnormal or emergency conditions.
- The proper procedure to lock out and mark controls prior to allowing or commencing maintenance on the equipment.
- The proper procedure to obtain clearance to remove lockouts and out-of-service marks and return the equipment to normal service.

SECTION II

PREPARATION FOR USE AND RESHIPMENT

- 2-1. **Unpacking Equipment.** Inspect outer cartons for evidence of damage during shipment prior to unpacking. *Claims for damage in shipment must be filed promptly with the transportation company involved.* Otherwise unpack the units with care and retain package materials for any reshipment. MDL1120 see special handling on page 16
- 2-2. **Pre-installation Inspection.** Conduct a thorough inspection of the units, paying particular attention to the following items:
- Screws in place and tight.
 - All panels and fins free of dents and scratches.
 - RF connector visually OK. While inspecting RF connector, measure DC resistance of the unit by reading from the center conductor to the outer conductor. Compare this reading to that on the specification sheet at the end of this manual. Reading should be ± 2 ohms. If not, consult factory.
 - Replace shipping plug with the vent plug. Keep the shipping plug with the unit for future maintenance or shipping.

WARNING

The vent plug must be used at all times when operating the unit or when the unit is cooling. Failure to do so could result in an explosion causing severe burns.

- 2-3. **Pre-installation Test.** Verify the thermal switch is closed by connecting an ohmmeter or a battery-operated test lamp across the $\frac{1}{4}$ inch spades on the switch. For units with fans, connect the unit to a suitable source of AC power. Turn main switch on and check for quiet fan operation.
- 2-4. **Installation.** The Model 1100 Series RF Coaxial Load must be installed in a location convenient for servicing. Consideration should be given to adequate accessibility for maintenance and unit replacement. No attempt is made in this handbook to present complete installation instructions, since physical differences in facilities will determine the installation procedure. General guidelines are outlined in subsequent paragraphs.
- 2-5. **Location.** Locations selected for the Model 1100 Series Load should have an ambient temperature between +5 F (-15 C) and 104°F (40°C) for operation. The room should be well ventilated to prevent excessive temperature rise and consequent derating of the unit. The location must allow sufficient area to allow clearance of at least 12 inches (30cm) around all

sides of the load (with exception to dual load application) and free from 36" from combustible materials.

- 2-6. Mounting.** The Model 1100 Series Loads are designed to be portable or used in a fixed installation. It is to be installed in a horizontal position only with the vent plug facing upward. Floor is the preferred location for all loads. The Mdl1120 loads may be mounted to ceiling using code approved mounting techniques. (engineering may be required in some location). Min of 36" space above load to ceiling. In a temperature-controlled environment with adequate space for air circulation.
- 2-7. Connections.** There are two connections on conventional RF coaxial oil cooled loads: the RF connection on the front panel of the unit and the thermal interlock switch. Connect the RF transmission line using standard coaxial line coupling kits appropriate for the frequency and power level of operation. The thermal interlock switch consists of two ¼ inch spades connecting to the interlock circuit.
- 2-8. Preparation for Reshipment.** Remove the vent plug and replace it with the shipping plug. Wrap the vent plug with protective padding and secure it to the load. It is not necessary to drain the coolant with the shipping plug in place. Wrap the RF connector in protective padding. Packaging should provide protection against abrasion and impact.

SECTION III

OPERATING INSTRUCTIONS

- 3-1. Normal Operation.** The Model 1100 Series RF Coaxial Loads are passive devices. There are no indicators or operating controls. Turn on RF power at the source. Follow instructions for the specific generator equipment.
- 3-2. Shutdown.** Turn off RF power at the source. The installed interlock will automatically shut down the transmitter unit when properly connected if an overheat condition exists.
**FAILURE TO INSTALL INTERLOCK OR PROVIDE AC POWER WHILE APPLYING RF POWER WILL DAMAGE LOAD, SITE EQUIPMENT AND MAY EXPEL HOT OIL THAT COULD CAUSE SEVERE BURNS.
WHICH WILL VOID WARRANTY.**

SECTION IV

MAINTENANCE

WARNING!!

BEFORE PERFORMING ANY MAINTENANCE:

1. **DISCONNECT RF CONNECTOR ASSEMBLY.**
2. **OPEN TRANSMITTER VSWR INTERLOCK CIRCUIT.**

**FAILURE TO FOLLOW THESE DIRECTIONS
MAY CAUSE FATAL ELECTRICAL SHOCK!**

- 4-1. **Cleaning.** The enclosure of the Model 1100 Series RF Coaxial Load is finished with a durable coating system. Periodically wipe free of dust and dirt as needed. Heat dissipation can be reduced if excessive dust is allowed to accumulate on the cooling fins. The RF connector should be cleaned with a non-residue contact cleaner. Check for any coolant leakage or corrosion at this time.
- 4-2. **DC Resistance.** Start DC resistance tracking before the load is put into service and measure annually thereafter. Measure with an accurate ohmmeter on the load when it is at a temperature between 20 and 25°C (68-77°F) following these steps:
- a. Turn off RF power and interlock circuitry.
 - b. Disconnect RF line.
 - c. Connect the meter test lead to the center and outer conductor of the load resistor.
 - d. Compare the reading with the previous reading and with the baseline resistance when the load was put into service. A difference of more than 2 ohm from the previous or baseline reading could indicate a failing resistor.
- 4-3. **Coolant.** Coolant lifetime is unlimited if operated in normal load rating range.

Dielectric Oil Volume in Gallons:

<u>MODEL 1101</u>	<u>MODEL 11015</u>	<u>MODEL 11025</u>	<u>MODEL 1105</u>	<u>MODEL 1110</u>	<u>MODEL 1120</u>
1.64	2.17	2.95	8.2	8.2	17


4-4. **RF Circuit.** The RF Load Resistor does not require any periodic maintenance and the only repairs possible are the replacement of parts in the connector or support portions of the resistor assembly or the replacement of resistors.

4-5. **Resistor Replacement.** Consult factory



SECTION V

OUTLINE DRAWINGS

Published On 10/24/16




- NOTES:**
1. WEIGHT WITH OIL IS APPROXIMATELY 33.32[15.11]
 2. WEIGHT WITHOUT OIL IS APPROXIMATELY 21.93[9.95]





STEP	PROCESS	MIN	MAX	DATE	BY	CHK	REV	DESCRIPTION

TOLERANCES (EXCEPT AS NOTED)		MATERIAL		FINISH		DRAWN		CHECKED		DATE	
DECIMAL	± .005	FRAC	1/32	PLATE	304 SS	304 SS					
ANGULAR	± 0.1°	FRAC	1/16	FINISH							
DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED											

ALTRONIC RESEARCH, INC.		YUKON, ARIZONA 86097, U.S.A.	
1KW OIL LOAD			
REV	C	PART NO.	MDL1101
SCALE:		SHEET:	2 OF 3



- NOTES:
1. WEIGHT WITH OIL IS APPROXIMATELY 48.83[22.15]
 2. WEIGHT WITHOUT OIL IS APPROXIMATELY 33.82[15.34]




DEC. PROCES.	STAMP	REV.	DATE	DESCRIPTION

Altronic Research, Inc.
Tulsa, Oklahoma 74107, U.S.A.



DESCRIPTION: 1.5 kW OIL LOAD

REV: C PARTNO: MDL11015

SCALE: SHEET 2 OF 2



- NOTES:
1. WEIGHT WITH OIL IS APPROXIMATELY 42.75[28.44]
 2. WEIGHT WITHOUT OIL IS APPROXIMATELY 42.33[19.2]



DEC. PROCES.	STAMP	REV.	DATE	DESCRIPTION


Altronic Research, Inc.
Tulsa, Oklahoma 74107, U.S.A.

DESCRIPTION: 2.5 kW MS OIL LOAD


REV: C PARTNO: MDL11025-MS

SCALE: SHEET 2 OF 2

Revised On 11/19/23



md1120



SPECIFICATIONS

Model 1100 Series RF Coaxial Load

Impedance ----- 50 ohms nominal

VSWR 1100 Series: DC to 1000 MHz

Models 1101, 11015, 11025 ----- 1.1:1 Max.

Models 1105, 1110 ----- <1.15:1

VSWR Digital 1100D series: 470-890 MHz

Models 1101D, 11015D, 11025D ----- 1.065:1 Max.

Models 1105D, 1110D, 1120D ----- <1.1:1

Connectors:

Model QC ----- > QC connector

Model E1 ----- > 1-5/8" EIA flange

Model E3 ----- > 3-1/8" EIA flange

Power Rating @ Sea Level:

Models 1101, 1101D and 1101MS ----- 1 KW

Models 11015 and 11015D and 11015MS ----- 1.5 KW

Models 11025 and 11025D and 11025MS ----- 2.5 KW

Models 1105 and 1105D and 11005MS ----- 5 KW

Models 1110 and 1110D and 11010MS ----- 10 KW

Models 1120 and 1120D and 1120MS ----- 20 KW

Frequency Range

1100 series ----- DC to 1000 MHz

Digital 1100D series ----- 470 to 890 MHz

Digital 1100ms series ----- 110kHz to 30 MHz

Cooling Method ----- Dielectric Oil, Static/fan air

Operating Temperature ----- 5 to 40°C (41 to 104°F)

Storage Temperature ----- -40 to +45°C (-40 to +113°F)

Altitude* ----- 5,000 ft (1520 m)

*(*derate RF power by 2.5% for every 1,000 ft (305m) above 5,000 ft. (1,520m.)*

Humidity ----- 95% noncondensing max

Finish ----- Blue Powder Coating

Serial No. _____ Frequency _____ Resistance _____ dBA @ 3' 0

Model _____ Inspected by _____ Date _____



CRAFTED WITH PRIDE IN ARKANSAS, U.S.A.

SPECIAL HANDLING

Model 1120 Series RF Coaxial Load

Loads weigh close to 300# /136kg. With oil removed the weight is reduced by approximately 100#/45kg to allow for transport by hand



Arrival condition



Remove bands and plywood covers.

Remove Torx head screws with provided driver bit. Unit may be slide over on a standard pallet jack to transport to install position. Once on pallet jack unit can be rolled to location and set in place. (Note: For long or uneven floors loads should be locked on pallet jack with straps.)



Once load is in position remove smaller oil plug and add all the oil provided. Check oil level with provided dip stick, record with a photo, and retain for warranty registration. Install provided vent cap.



For installation with forklift and oil pre-installed please use the following. Use included eye bolts and pipe to lift. Assure pipe caps are secured to pipe. **Do not lift using fork under pipe. Pipe only can roll causing a drop.**

LOAD CANNOT BE LIFTED FROM BOTTOM FAN BOX



CEILING MOUNTING

Floor is the preferred location for all loads. The Md11120 loads may be mounted to ceiling using code and safety approved mounting techniques (engineering may be required in some location). Min of 36” space above load to ceiling. Well-ventilated environment with adequate space for air circulation is required.